

220-240V / 50-60Hz

**Terminal Labelling:**

**Power**


L1 Switched Live  
E Earth  
N Neutral

**Emergency**


L2 Unswitched Live  
DA/AT3 DALI Autotest  
DA/AT3 DALI Autotest

**Dimming**


-/D1/DA Analogue/DSI/DALI  
+/D2/DA Analogue/DSI/DALI  
L3 Switch Dim / Corridor Function



**WARNING:** Luminaire must be earthed. Risk of electric shock from LED boards if operated with cover removed. Installation / operation outside of luminaires intended scope invalidates warranty. Suitable only for domestic / light industrial / industrial applications within the scope of EN55015. Tested to compliance with BSEN 60598: specification for general requirements and tests. Must be installed by a suitably qualified person in accordance with all relevant legislation. Ambient operating temperature of 0°C to 25°C. If maximum operating temperature is exceeded luminaire will automatically dim / switch off. Terminal blocks are rated to 16A unless stated otherwise. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. **LUMINAIRES WITH EMERGENCY PACK:** When supply is isolated battery output terminals may be live if battery is connected. Isolate mains and battery before servicing. Emergency luminaires require unswitched live connection taken from same phase as switched supply. When unswitched supply is connected status indicator illuminates green, when unswitched supply is disconnected indicator extinguishes and luminaire operates in emergency mode. 24 hour charge period required before undertaking full discharge test. Emergency test sheets provided should be used to record all emergency tests. Batteries should be replaced when 3 hour duration is not met. Excessive switching of permanent live may result in premature battery failure. Battery electrolyte can be harmful to eyes / open wounds, do not puncture, if electrolyte touches skin / eyes flush with water. Do not incinerate batteries.




COULIS 80




COULIS 90


**1. Fit the Coulis in track driver inside the track**




**2. Ensure the notch on the fitting is positioned opposite the notch on the track**



**3. Once installed, rotate the lever to lock it in place.**




**4. Finally, select the correct phase (1, 2, or 3)**




## Maintenance Guide

Disconnect the luminaire before undertaking any maintenance or cleaning.  
 Cleaning should be undertaken on external parts of the luminaire only, using a slightly damp, lint-free cloth.




### Cob Access

- Pinch to release the reflector from the Coulis Housing.
- Once removed, the COB can be replaced by loosening two screws and disconnecting the wires.



### Driver Access

- Loosen the two screws (Circled)
- Pinch the tabs to release the cover.
- Remove the cover, then disconnect the wires to replace the driver.



Please contact Dextra for assistance with spare component supply.