








LED4 Surface Installation

Mounting Instruction




Dimensions in mm






LED4 Surface Installation






Terminal Description



Battery Connection



Battery Exchange



For re-connection of EM R2A
start in reverse order